



**INSTRUCTION,
MAINTENANCE
and
PARTS MANUAL**

CM METEOR[®]

SERIES S. A.

ELECTRIC HOIST

Equipped With Meteor Monitor™

CAPACITY: FROM 1/2 TO 5 TON

Caution — Important

If not properly installed, operated and maintained, the use of all mechanical equipment presents the possibility of personal injury or property damage. Before hoist use, all persons who will install, operate or maintain should read this manual thoroughly. For safe, dependable and economical performance, follow all instructions and recommendations contained herein. It is also important to retain this manual for future use.



CM HOIST

DIVISION COLUMBUS MCKINNON CORPORATION
TONAWANDA, NEW YORK 14150 U.S.A.

83876

© 1976 Columbus McKinnon Corporation

MANUAL NO. 81G

PRICE \$2.50

DO'S AND DON'TS

Safe Operation of Hoists

The following are Do's and Don'ts for safe operation of overhead hoists. Taking precedence over any specific rule listed here, however, is the most important rule of all, USE COMMON SENSE. A few minutes spent reading these rules can make an operator aware of dangerous practices to avoid and precautions to take for his own safety and the safety of others. Frequent examinations and periodic inspections of the equipment as well as a conscientious observance of safety rules may save lives as well as time and money.

DON'TS — HOISTS

1. NEVER lift or transport a load until all personnel are clear.
2. DO NOT allow any unqualified personnel to operate hoist.
3. NEVER pick up a load beyond the capacity appearing on the hoist. Overloading can be caused by jerking as well as by static overload.
4. NEVER carry personnel on the hook or the load.
5. DO NOT operate hoist if you are not physically fit.
6. DO NOT operate hoist to extreme limits of chain or rope.
7. AVOID sharp contact between two hoists, between hoist and end post, and hooks and hoist body.
8. DO NOT tamper with any parts of the hoist.
9. NEVER use the hoist rope or chain as a sling.
10. DO NOT divert attention from load while operating hoist.
11. NEVER leave a suspended load unattended.
12. DO NOT attempt to lengthen load chain, or to repair damaged load chain.
13. DO NOT use chain or rope as ground for welding. NEVER touch a live welding electrode to the chain or rope.

DO'S — HOISTS


1. READ and follow manufacturer's instruction, installation and maintenance manuals. When repairing or maintaining a hoist, use only manufacturer's recommended parts and materials.
2. READ and follow all instruction and warning information on or attached to a hoist.
3. REMOVE the hoist from service and thoroughly inspect and repair as necessary if unusual performance or visual defects (such as peculiar noise, jerky operations, or travel in improper direction or obviously damaged parts) are noticed.
4. ESTABLISH a regular schedule of inspection and maintain records for all hoists with special attention given to hooks, ropes, chains, brakes and limit switches.
5. CHECK operation of brakes for excessive drift.
6. CHECK operation of limit switches.
7. CHECK for damaged hooks, ropes or chain.
8. KEEP load chain or rope clean and well lubricated.
9. CHECK the wire rope or chain for improper seating, twisting, kinking, wear or other defects before operating the hoists.
10. CHECK for broken wires in wire rope. Twelve randomly distributed broken wires in one rope lay or four broken wires in one strand in one rope lay are sufficient cause for replacement.
11. MAKE SURE a load clears neighboring stock piles, machinery, or other obstructions when raising, lowering, or traveling the load.
12. CENTER hoist over the load before operating.
13. AVOID swinging of load or load hook when traveling the hoist.
14. BE SURE the load attachment is properly seated in the saddle of the hook. Balance load properly before handling. Avoid tip loading.
15. PULL in a straight line, so that neither hoist body nor load chain or rope are angled around an object.
16. MAKE SURE you take up slack slowly.
17. ON LEVER OPERATED HOISTS, always release handle gradually when under load to avoid flying handle.

Above reprinted from Hoist Manufacturers Institute "Do's and Don'ts."

CONTENTS

SECTION A — INSTALLATION	Page No.	SECTION E — REPAIR PARTS LIST	Page No.
All Hoists	3-4	Ordering Instructions	26
Lug Suspension	5	Hoist Arrangement	26
Hook Suspension	6	Reeving Components —	
All Trolleys	6	Two-Part Rope Hoist	27-28
Plain and Geared Trolleys	6	Reeving Components —	
Motor Driven Trolleys	7	Four-Part Rope Hoist	27-28
Current Collectors and Wiring	7-8	Reeving Components —	
Adjustable Screw Limit Switch	8	Six-Part Rope Hoist	27-28
SECTION B — OPERATION		Control End Components	27-28
General	8-9	Hoist Frame & Motor-Brake Components	27-28
Operating Instructions	9	Gearing End Components	27-28
Safety Procedures	9	Electric Brake &	
SECTION C — MAINTENANCE		Weatherproof Brake Housing	27-28
General	10	Upper Limit Switch	27-28
Periodic Inspection and		Adjustable Screw Limit Switch	27-28
Maintenance Procedure	10-11	Hoist Motor	27-28
Hoist Lubrication	11	Plain & Geared Trolleys	29-30
Trolley Lubrication	12	Motor Driven Trolleys	29-30
Adjustments	12-16	Trolley Motor	29-30
SECTION D — TROUBLE SHOOTING		Motor Driven Trolley Motor Brake	29-30
Procedure	16-19	Contactors	31-33
Wiring Diagrams	20-24	Control Stations	33-37
Open and Short Circuits	24	Hook & Lug Suspensions	38
Electrical Data	25	Current Collectors	39-41


Enclosed Conductor System Current Collectors



***NUMBER 100E**

COLLECTOR ASSEMBLY PARTS LIST

Part No.	No. Req'd.	Part Name
*100E	3	Collector Assembly
601 BC	1	Clamp only
601 BS	1	Swivel only
601 P	1	Post
601 E	1	Standard Arm
601 Y	1	Yoke
601 AD	2	Case Half
100 S	1	Shoe
100 Y	1	Shoe Clip
100 Z	1	Spring
COM 1	1	3/8 — 16 Hex Nut
COM 2	1	3/8 Lockwasher
COM 3	1	3/8 — 16 x 1 1/2 Bolt
COM 4	2	1/4 — 20 x 1 Machine Screw
COM 5	3	1/4 — 20 Hex Nut
COM 6	1	1/4 Lockwasher
COM 7	1	1/4 — 20 x 1/2 Bolt
COM 8	2	1/4 x 1 1/4 Roll Pin
COM 9	2	Dot Fastener
COM 10	1	No. 6 Non-Insulated Terminal
COM 11	1	1/2 Retaining Ring



NUMBER 70E

COLLECTOR ASSEMBLY PARTS LIST



Part No.	No. Req'd.	Part Name
70 E	3	Collector Assembly
601 BC	1	Clamp only
601 BS	1	Swivel only
601 P	1	Post
601 E	1	Standard Arm
701 Y	1	Yoke
707	2	Case Half
70 S	1	Shoe
100 Z	1	Spring
COM 1	1	3/8 — 16 Hex Nut
COM 2	1	3/8 Lockwasher
COM 3	1	3/8 — 16 x 1 1/2 Bolt
COM 5	1	1/4 — 20 Hex Nut
COM 6	1	1/4 Lockwasher
COM 7	1	1/4 — 20 x 1/2 Bolt
COM 8	2	1/4 x 1 1/4 Roll Pin
COM 10	1	No. 6 Non-Insulated Terminal
COM 11	1	1/2 Retaining Ring

***ASSEMBLIES DISCONTINUED. INDIVIDUAL COMPONENTS AVAILABLE FOR REPAIRS ONLY.**

Current Collectors

*SHOE COLLECTOR FOR BARE COPPER WIRE CONDUCTOR SYSTEM

*WHEEL COLLECTOR FOR BARE COPPER WIRE CONDUCTOR SYSTEM




*ASSEMBLIES DISCONTINUED. INDIVIDUAL COMPONENTS AVAILABLE FOR REPAIRS ONLY. REFER TO PAGE 41 FOR MOUNTING INSTRUCTIONS.
 **INDIVIDUAL PART NOT AVAILABLE. CONTACT FACTORY FOR REPLACEMENT.


Parts List

Key No.	No. Req'd.	Part Name	Key No.	No. Req'd.	Part Name
*WS-723	1	Shoe Collector Assembly (Items WS-725 Thru WS-730 & Three WS-732; Specify Size of I-Beam & Capacity of Hoist)	WS-736	2	Collector Shoe Clamp Screw Nut
*WS-724	1	Wheel Collector Assembly (Items WS-725 Thru WS-730 & Three WS-750; Specify Size of I-Beam & Capacity of Hoist)	WS-737	1	Collector Shoe Clamp Screw
WS-725	1	Collector Bar Bracket	WS-738	1	Collector Shoe Cotter Pin
WS-726	2	Collector Bar Bracket Attaching Screw	*WS-750	3	Wheel Collector (Items WS-751 Thru WS-769)
WS-727	2	Collector Bar Bracket Attaching Screw Lockwasher	WS-751	1	Clamp Bearing and Rivet
WS-728	2	Collector Bar Bracket Set Screw	WS-752	1	Clamp
WS-729	1	Collector Bar (Specify Whether for Shoe or Wheel Collector, Size of I-Beam & Capacity of Hoist)	WS-753	1	Clamp Screw
WS-730	1	Collector Bar Insulator	WS-754	1	Clamp Screw Lockwasher
*WS-732	3	Shoe Collector (Items WS-733 Thru WS-738)	WS-755	1	Clevis Pin & Rivet
WS-733	1	Collector Shoe	WS-756	1	Collar & Rivet
WS-734	1	Collector Shoe Clamp Screw Washer	WS-757	1	Rivet
WS-735	2	Collector Shoe Clamp Screw Lockwasher	**WS-758	1	Harp
			WS-759	1	Harp Pin, Washer & Cotterpin
			WS-760	1	Spring
			WS-761	1	Wheel
			WS-762	1	Wheel Pin
			WS-763	1	Wheel Pin Cotter Pin
			WS-764	1	Copper Shunt
			WS-765	3	Shunt and Terminal Screw
			WS-766	3	Shunt and Terminal Screw Lockwasher
			WS-767	3	Shunt and Terminal Screw Washer
			WS-768	1	Harp Pin Washer
			WS-769	1	Harp Pin Cotter Pin


Hook and Lug Suspension



1/2-3 TON HOOK SUSPENSION



5 TON HOOK SUSPENSION




1/2-5 TON LUG SUSPENSION

Parts List

Key No.	No. Req'd.	Part Name
WS-269	2	Latch Kit (1/2-3 Ton #7 Latch Kit, 5 Ton #8 Latch Kit), Specify Hook Size (Not Shown)
WS-325	1	Lug Suspension — 1/2-3 Ton Units (Items WS-326 Thru WS-328 & WS-330)
WS-326	2	Hoist Suspension Bolt (Specify Length of Bolt)
WS-326	2	Hoist Suspension Pin (5 Ton Hook Suspension)
WS-327	4	Hoist Suspension Bolt Nut
WS-328	4	Hoist Suspension Bolt Nut Cotter Pin
WS-329	4	Hoist Suspension Pin Cotter Pin
WS-329	2	Idler Sheave Housing Support Pin Cotter Pin
WS-330	76	Spacer Washer — 1/2-3 Ton Units
WS-330	36	Spacer Washer — 5 Ton Units
WS-335	1	Lug Suspension — 5 Ton Units (Items WS-326 Thru WS-330 & WS-336)
WS-336	1	Idler Sheave Housing Support Pin (Specify Length of Pin). For other type Pin see Page 28.
WS-345	1	Hook Suspension — 1/2-3 Ton Units (Items WS-326 Thru WS-328 & WS-346)
WS-346	1	Upper Hooks and Channel Assembly
WS-355	1	Hook Suspension — 5 Ton Units (Items WS-326, WS-329, WS-336 & WS-356 Thru WS-361)
WS-356	1	Hook Suspension Channel
WS-357	2	Upper Hook—Latchlok
WS-358	4	Upper Hook Washer
WS-359	2	Upper Hook Nut
WS-360	2	Upper Hook Nut Pin
WS-361	2	Idler Sheave Housing Support Pin Washer

REFER TO PAGE 26 FOR ORDERING INSTRUCTIONS

Push Button Stations Series D




Parts List

Key No.	No. Req'd.	Part Name	Key No.	No. Req'd.	Part Name
WS-64	2	Push Button Chain Attaching Link	WS-787	1	Box
WS-68		Push Button Chain (Specify Length Req'd.)	WS-788	4 or 6	Cover Attaching Screw
WS-69		Push Button Cable (Specify Length Req'd.)	WS-789	4 or 6	Cover Attaching Screw Lockwasher
WS-90		Push Button Cable Clip (Specify No. Req'd.)	WS-790	1	Cover Gasket (For Weatherproof Station)
WS-783	1	Push Button Chain Clip	WS-793	1 or 2	Switch Unit (Specify Button Markings Req'd.; State Whether for "Hoist" or "Trolley")
WS-784	1	Push Button Box Connector	WS-815	2	Name Plate (Specify Markings Req'd.)
WS-785	1	2-Push Button Station (Specify Button Markings Req'd.) (Items WS-786 Thru WS-789, WS-793 & WS-830)	WS-816	4	Name Plate Drive Screw
WS-785	1	4-Push Button Station (Items WS-786 Thru WS-789, WS-793, WS-815, WS-816, WS-830 Thru WS-834)	WS-830	1 or 2	Liner
WS-786	1	Cover (For 2-Button Station)	WS-831	8	Switch Attaching Screw
WS-786	1	Cover With Name Plates (For 4-Button Station)	WS-832	8	Switch Attaching Screw Lockwasher
			WS-833	1	External Ground Screw Washer
			WS-834	1	External Ground Screw

REFER TO PAGE 26 FOR ORDERING INSTRUCTIONS

Control Station – Hoist Trolley Combination



Parts List


Key No.	No. Req'd.	Part Name	Key No.	No. Req'd.	Part Name
WS-774	1	Control Station Parts Kit consists of: 2—Terminal Attaching Screw 1—Strain Cable Attaching Screw 1—Strain Cable Attaching Screw Washer 4—Pin Retainer Screw 8—Switch Leaf Spring 2—Switch Mounting Pin 4—Terminal	WS-776	1	Case
			WS-777	1	Gasket
			WS-778	1	Cover Assembly (Decal & Rocker Included)
			WS-781	1	Control Station Kit consists of: 1—Grommet 1—Control Station Chain Clip 2—Chain Clip Attaching Screw 6—Cover Screw
WS-775	1	Control Station Switch Kit consists of: 8—Switch 1—Jumper 2—Jumper	WS-785	1	Control Station (Items WS-774 thru WS-778 & WS-781)

REFER TO PAGE 26 FOR ORDERING INSTRUCTIONS

Control Station – Two Speed Hoist Parts List

Key No.	No. Req'd.	Part Name
WS-774	1	Control Station Parts Kit consists of: 1—Spring 1—Strain Cable Attaching Screw 1—Strain Cable Attaching Screw Washer 2—Switch Attaching Pin 1—Sliding Cam 2—Spring End Support 3—Switch Mounting Plate & Rocker Assembly Attaching Screw 1—Switch Mounting Plate & Rocker Assembly 1—Cam Return Spring


Key No.	No. Req'd.	Part Name
WS-775	1	Control Station Switch Kit consists of: 3—Switch 2—Insulator 1—Jumper
WS-776	1	Case
WS-777	1	Gasket
WS-778	1	Cover Assembly (Decal & Rocker Included)
WS-781	1	Control Station Kit consists of: 1—Grommet 1—Control Station Chain Clip 2—Chain Clip Attaching Screw 6—Cover Attaching Screw
WS-785	1	Control Station (Items WS-774 thru WS-778 & WS-781)



Control Station – Single Speed Hoist

Parts List

Key No.	No. Req'd.	Part Name	Key No.	No. Req'd.	Part Name
WS-774	1	Control Station Parts Kit consists of: 1—Strain Cable Attaching Screw 1—Strain Cable Attaching Screw Washer 2—Switch Mounting Pin 3—Pin & Jumper Retainer Screw 2—Switch Leaf Spring	WS-776	1	Case
WS-775	1	Control Station Switch Kit consists of: 2—Switch 1—Jumper	WS-777	1	Gasket
			WS-778	1	Cover Assembly (Decal & Rocker Included)
			WS-781	1	Control Station Kit consists of: 1—Grommet 1—Control Station Chain Clip 2—Chain Clip Attaching Screw 4—Cover Attaching Screw
			WS-785	1	Control Station (Items WS-774 thru WS-778, & WS-781)




Parts List

Key No.	No. Required		Part Name	Key No.	No. Required		Part Name
	Reversing Contactor	Selecting Contactor			Reversing Contactor	Selecting Contactor	
WS-610	1		Reversing Contactor	WS-627	4	2	Coil Retainer
WS-611		1	Speed Selecting Contactor	WS-628	4	2	Yoke Trunnion, Screw and Lockwasher
WS-612	1	1	Back Plate, Side Plates and Screws	WS-629	0	2	Jumper
WS-613	2	1	Coil	WS-630	8	4	Stationary Contact Block Attaching Screw
WS-614	2	1	Yoke Spring, Right Hand	WS-631	2	1	Armature
WS-615	2	1	Yoke Spring, Left Hand	WS-632	4	2	Wire Retainer
WS-616	0 or 1	1	Terminal Block Kit (Block, Terminals & Screws)	WS-633	3	3	Contacting Attaching Screw
WS-617	2	0	Rocker Arm With Bracket	WS-634	3	3	Contacting Attaching Screw Washer
WS-618	2	0	Mechanical Interlock Bar	WS-635	3	3	Grommet, large
WS-619	0 or 2	2	N. C. Contact Kit	WS-636	2	1	Field With Brackets & Shading Coils
WS-620	6	2	N. O. Contact Kit	WS-637	8	4	Field Attaching Screw, Washer and Nut
WS-621	0 or 4	0	Dummy Contact Kit	WS-638	8	4	Grommet, small
WS-622	2	1	Stationary Contact Block	WS-639	0	1	Reinforcing Bar
WS-623	2	1	Upper and Lower Movable Contact Blocks and Screw (WS-642)	WS-640	16	10	Quick Connect Terminal
WS-624	4	2	Movable Contact Block Assembly Screw	WS-641	16	8	Quick Connect Terminal Screw
WS-625	4	2	Movable Contact Block Assembly Screw Lockwasher	WS-642	2	1	Movable Contact Block Screw
WS-626	3 or 4	0	Connector	WS-643	2	1	Yoke
				WS-644	4	2	Shading Coil

REFER TO PAGE 26 FOR ORDERING INSTRUCTIONS

Push Button Stations Series R




Parts List


Key No.	No. Req'd.	Part Name
WS-784	1	Push Button Box Connector
WS-785	1	2-Push Button Station Discontinued — Control Station Page 35 will be furnished
WS-785	1	4-Push Button Station Discontinued — Control Station Page 36 will be furnished

ALSO, INDIVIDUAL COMPONENTS FOR THESE STATIONS ARE **NOT** AVAILABLE.

Contactor Type BW



Contactor Type D



Parts List

Key No.	No. Req'd.	Part Name
WS-645	1	Contactor (Items WS-646 Thru WS-666)
WS-646	2	Contact Block Screw With Lockwasher
WS-647	1	Contact Block With Stationary Contact Screws & Lockwashers
WS-648	12	Stationary Contact Screw
WS-649	12	Stationary Contact Screw Lockwasher
WS-650	2	Contact Carrier
WS-651	6	Movable Contact
WS-652	6	Contact Spring Retainer
WS-653	6	Contact Spring
WS-654	1	Base With Bushings
WS-655	1	Mechanical Interlock
WS-656	1	Interlock Latch
WS-657	2	Coil Washer
WS-658	2	Magnet Coil
WS-659	4	Coil Terminal Screw With Lockwasher
WS-660	4	Slip-on Connector
WS-661	1	Coil Jumper
WS-662	2	Armature With Lockwasher & Nut
WS-663	2	Armature Slotted Nut
WS-664	2	Armature Nut Lockwasher
WS-665	1	Bottom Plate
WS-666	2	Bottom Plate Screw With Lockwasher
WS-667	1	Electrical Interlock Assembly (N.C. Contacts)
WS-668	1	Contact Kit (Items WS-648, WS-649, WS-651 & WS-653)

ADJUSTMENT — If armature solenoid is removed, it should be adjusted when reassembled by screwing armature within 15/64 of magnet core and locking with slotted nut to 20 in.-lbs. torque.

REFER TO PAGE 26 FOR ORDERING INSTRUCTIONS

SECTION E – REPAIR PARTS LIST

Ordering Instructions

The following information must accompany all correspondence or repair parts orders:

- 1) Hoist Model Number.
- 2) Serial Number of Hoist and/or Motor Driven Trolley.
- 3) Voltage, Phase, Hertz.

This information is stamped on the hoist name plate. Hoist serial number is also stamped on control end of right suspension lug.

The Motor Driven Trolley serial number is stamped on end of motor side frame.


When ordering hoist and/or trolley motor parts, give the motor name plate data in addition to the above.

For parts orders specify:

- 1) Quantity desired.
- 2) Key number of part.
- 3) Part name.

NOTE: When ordering replacement parts, it is suggested that the individual also consider the need (if he has not done so already) for such items as gaskets, oil seals, fasteners, etc. These items may be damaged or lost during the disassembly or may be just unfit for future service because of deterioration from age or service conditions.


Hoist Arrangement



- A – Reeving Components
- B – Control End Components
- C – Hoist Frame & Motor-Brake Components
- D – Gearing End Components

Electrical Data

MOTORS		Current (Amps.)		Lead No.	D. C. Resistance (Ohms)	MOTORS		Current (Amps.)		Lead No.	D. C. Resistance (Ohms)		
Voltage-Phase-Hertz	H. P.	Starting	Full Load			Voltage-Phase-Hertz	H. P.	Starting	Full Load				
230/460-3-60	2	29/14.5	6.2/3.1	T1-T4 T2-T5 T3-T6 T7-T8 T7-T9 T8-T9	2.3 4.7	230-3-60	4/1.33	74/27	13.6/11.6	T1-T2 T1-T3 T2-T3 T11-T12 T11-T13 T12-T13	2.6 1.3		
230/460-3-60	3	44/22	9/4.5	T1-T4 T2-T5 T3-T6 T7-T8 T7-T9 T8-T9	1.7 3.3	230-3-60	4.5/1.5	74/27	14.4/12	T1-T2 T1-T3 T2-T3 T11-T12 T11-T13 T12-T13	2.6 1.3		
230/460-3-60	4	66/33	10.6/5.3	T1-T4 T2-T5 T3-T6 T7-T8 T7-T9 T8-T9	1.3 2.4	460-3-60	4/1.33	37/13.5	6.5/5.8	T1-T2 T1-T3 T2-T3 T11-T12 T11-T13 T12-T13	11.5 5.2		
230/460-3-60	4.5	66/33	12/6	T1-T4 T2-T5 T3-T6 T7-T8 T7-T9 T8-T9	1.3 2.4	460-3-60	4.5/1.5	37/13.5	7.2/6	T1-T2 T1-T3 T2-T3 T11-T12 T11-T13 T12-T13	11.5 5.2		
230-3-60	2/.67	25/9.6	6/5.2	T1-T2 T1-T3 T2-T3 T11-T12 T11-T13 T12-T13	6.3 3.5	TRANSFORMER							
460-3-60	2/.67	12.5/4.8	3/2.6	T1-T2 T1-T3 T2-T3 T11-T12 T11-T13 T12-T13	24.5 12.2	Voltage		Leads		D.C. Resistance (Ohms)			
						230/460 to 115		Secondary: R - R Primary: 16 - 17 18 - 19		15 50 50			
230-3-60	3/1	32/14	8.5/8.0	T1-T2 T1-T3 T2-T3 T11-T12 T11-T13 T12-T13	4.6 2.3	BRAKE COIL							
						Voltage		Normal Current (Amps.)		D.C. Resistance (Ohms)			
						230		1.8		2.4			
						460		.9		9.3			
460-3-60	3/1	16/7	4.3/4.0	T1-T2 T1-T3 T2-T3 T11-T12 T11-T13 T12-T13	17.2 8.4	CONTACTOR COIL							
						Type Contactor		Voltage		Normal Current (Amps.)		D.C. Resistance (Ohms)	
						BW		115		.2		56	
						D		115		.2		105	





To Detect Open and Short Circuits In Electrical Components



Open circuits in the coils of electrical components may be detected by isolating the coil and checking for continuity with an ohmmeter or with the component in series with a light or bell circuit.



Shorted turns are indicated by a current draw substantially above normal (connect ammeter in series with suspected element and impose normal

voltage) or D.C. resistance substantially below normal. The current method is recommended for coils with very low D.C. resistance.



Motor current draw in the stator should be measured with the motor running. Brake and contactor coil current should be measured with the core iron in operating position.







NOTE: WIRING DIAGRAMS SHOWN ARE REPRESENTATIVE.
CONSULT DIAGRAM IN HOIST OR FURNISHED WITH UNIT.



Motor Driven Trolley

- | | | |
|--|-------------------------------------|--|
| 19) Trolley does not operate in either direction | a) No voltage at motor | Open circuit, grounded or faulty connection in hoist wiring. |
| | b) Phase failure | See Item 1b. |
| | c) Open control circuit | See Item 1c. |
| | d) Low voltage | See Item 1e. |
| | e) Wrong voltage or frequency | See Item 1d. |
| 20) Trolley operates in one direction only | a) Open control circuit | See Item 1c. |
| 21) Trolley operates sluggishly | a) Excessive load | See Item 1g. |
| | b) Low voltage | See Item 1e. |
| | c) Unbalanced current in the phases | See Item 1b. |
| | d) Brake dragging | See Page 12. |
| 22) Trolley motor overheats | | See Item 8. |

IF	CAUSE MAY BE	REMEDY
	b) Phase failure	See Item 1b.
10) Hoist will not operate at fast speed in either direction	a) Open circuit	See Item 9a.
	b) Open speed selecting—control circuit	Open or shorted winding in speed selecting contactor coil. Loose connection or broken wire in circuit. Mechanical binding in contactor. Control station contacts not making or opening.
	c) Phase failure	See Item 1b.
11) Hook will not raise at slow speed	a) Excessive load	See Item 6b.
	b) Phase failure	See Item 1b.
	c) Open speed selecting control circuit	See Item 9a.
	d) Brake not releasing	See Page 12.
	e) Open hoisting circuit	Open or defective thermal switch. Replace switch.
12) Hook will not lower at slow speed	a) Phase failure	See Item 1b.
	b) Open circuit	See Item 9a.
	c) Brake not releasing	See Page 12.
13) Hook will not raise at fast speed		See Item 11.
14) Hook will not lower at fast speed		See Item 12.
15) Hook moves in proper direction at one speed—wrong direction at other speed	a) Phase reversal	Wiring reconnected improperly. Interchange two leads of motor winding that is out of phase at the speed selecting contactor.
16) Hook fails to stop at upper limit	a) Slow acting brake	See Page 12.
	b) Upper limit switch not working	See Page 12.

Hoist Equipped with Adjustable Screw Limit Switch

17) Hook fails to stop at either or both ends of travel	a) Shaft not rotating	Drive pin or gear key damaged or omitted; gears damaged. Install or replace as necessary.
	b) Nut not moving along shaft	Guide screw damaged or missing; shaft or nut threads damaged. Install or replace as necessary.
	c) Switches not opening circuit	Check for electrical continuity and mechanical operation.
18) Hook stopping point varies	a) Not holding adjustment	See Item 17.
	b) Brake not holding	See Page 12.

IF	CAUSE MAY BE	REMEDY
		Check continuity, repair or replace defective part. Check operation of upper limit switch (see Page 12) and adjustable screw limit switch (Page 12).
	c) Phase failure	See Item 1b.
	d) Monitor relay not energized	See Page 8. (60 FPM units only).
	e) Monitor switch tripped	Lower load to floor to reset switch.
4) Hook raises but will not lower	a) Open lowering circuit	Open or shorted winding in reversing contactor coil; loose connection or broken wire in lowering circuit; control station contacts not making. Check continuity and repair or replace defective part. Check operation of adjustable screw limit switch Page 12.
5) Hook lowers when hoist control is operated	a) Phase failure	See Item 1b.
6) Hook does not stop promptly	a) Brake slipping	See Page 12.
	b) Excessive load	Reduce loading to the capacity limit of hoist as indicated on the identification plate.
7) Hoist operates sluggishly	a) Excessive load	See Item 6b.
	b) Low voltage	See Item 1e.
	c) Phase failure or unbalanced current in the phases	See Item 1b.
	d) Brake dragging	See Page 12.
8) Motor overheats	a) Excessive load	See Item 6b.
	b) Low voltage	See Item 1e.
	c) Extreme external heating	Above an ambient temperature of 104°F., the frequency of hoist operation must be limited to avoid overheating of motor. Special provisions should be made to ventilate the space or shield the hoist from radiation.
	d) Frequent starting or reversing	Excessive inching, jogging or plugging should be avoided since this type of operation will drastically shorten the life of motor and contactor and cause excessive wear on the brake.
	e) Phase failure	See Item 1b.
	f) Brake dragging	See Page 12.

Two Speed Hoist

9) Hoist will not operate at slow speed in either direction	a) Open circuit	Open or shorted motor winding, loose or broken wire in circuit. Speed selecting contactor stuck in opposite speed mode. Replace motor, repair wire and/or repair speed selecting contactor.
--	-----------------	---

Key No.	Req'd. No.	Part Name
WS-194	△ 2	Hook Block Sheave Bearing Washer
WS-195	* 1	Hook Block Sheave Snap Ring
WS-195	△ 2	Hook Block Sheave Snap Ring
WS-195	△ 1	Idler Sheave Snap Ring
WS-195	≅ 6	Hook Block Sheave Snap Ring
WS-195	≅ 2	Idler Sheave Snap Ring
WS-196	1	Lower Hook—Latchlok
WS-197	1	Lower Hook Nut Washer
WS-198	1	Lower Hook Nut
WS-199	1	Lower Hook Nut Pin
WS-200	1	Lower Hook Thrust Bearing
WS-220	1	Hook Block Assembly Items WS-186, WS-187, WS-189, WS-191, WS-193 Thru WS-196, WS-198 Thru WS-200, WS-221 & WS-222)
WS-221	1	Hook Block Center Cover
WS-222	2	Hook Block Sheave Shaft Snap Ring
WS-230	1	Idler Sheave Assembly (Items WS-191, WS-193, WS-195 & WS-231 Thru WS-234)
WS-231	1	Idler Sheave Shaft Keeper Plate
WS-232	1	Idler Sheave Shaft Keeper Plate Screw
WS-233	1	Idler Sheave Shaft Keeper Plate Screw Lockwasher
WS-234	1	Idler Sheave Shaft
WS-245	1	Hook Block Assembly (Items WS-190, WS-191, WS-193, WS-195, WS-196, WS-198 Thru WS-200, WS-246 Thru WS-256)
WS-246	2	Hook Block Side Plate
WS-247	2	Hook Block Sheave Shaft Nut
WS-248	2	Hook Block Sheave Shaft Nut Lockwasher
WS-249	2	Hook Block Sheave Bearing Spacer (End)
WS-250	2	Hook Block Sheave Bearing Spacer (Center)
WS-251	1	Hook Block Trunnion
WS-252	2	Hook Block Bolt and Nut
WS-253	4	Hook Block Bolt Lockwasher
WS-254	2	Hook Block Spacer
WS-255	2	Hook Block Capacity Plate
WS-256	1	Lower Hook Sleeve
WS-269	2	Latch Kit—Specify Hook Size (not shown)
WS-270	1	Idler Sheave Housing Assembly (Items WS-191, WS-193, WS-195, WS-231 Thru WS-234 & WS-271)
WS-271	1	Idler Sheave Housing
WS-280	1	Upper Limit Switch (Items WS-281 & WS-293 Thru WS-297)
WS-281	1	Upper Limit Switch Sub-Assembly (Items WS-282, WS-284 Thru WS-289)
WS-282	1	Limit Switch Housing With Bearing and Bracket
WS-283	1	Limit Switch Housing Bearing
WS-284	1	Limit Switch Cam Shaft
WS-285	1	Limit Switch Cam Shaft Return Spring
WS-286	1	Limit Switch Spring Retainer Screw
WS-287	1	Limit Switch Arm
WS-288	1	Limit Switch Arm Pin
WS-289	1	Limit Switch Housing Plug
WS-290	† 1	Limit Switch Bracket
WS-291	† 2	Limit Switch Bracket Screw
WS-292	† 2	Limit Switch Bracket Screw Lockwasher
WS-293	1	Limit Switch Bracket Insulating Shield
WS-294	2	Limit Switch
WS-295	2	Limit Switch Attaching Screw
WS-296	2	Limit Switch Attaching Screw Lockwasher
WS-297	2	Limit Switch Attaching Screw Nut
WS-308	2	Limit Switch Weight Screw
WS-309	2	Limit Switch Weight Screw Lockwasher
WS-310	1	Limit Switch Weight Sub-Assembly (Items WS-311 Thru WS-315)
WS-311	1	Limit Switch Open Link
WS-312	1	Limit Switch Weight Chain

* For 2 Part Rope
△ For 4 Part Rope
≅ For 6 Part Rope
† Discontinued — For Repairs Only


Key No.	Req'd. No.	Part Name
WS-313	1	Limit Switch Weight Ring
WS-314	1	Limit Switch Screw Eyebolt
WS-315	2	Limit Switch Weight
WS-336	1	Idler Sheave Housing Support Pin (Pin shown is for a hoist with Motor Driven Trolley. For other type pins see page 38)
WS-451	1	Power Cable
WS-452	1	Power Cable Connector
WS-501	1	Monitor Switch Assembly. (Includes WS-126, WS-504, WS-505 and WS-506)
WS-502	1	Mounting Plate SA (Includes WS-126, WS-504, WS-505 and WS-506) Replacement of this part requires the Re-Calibration of the Monitor switch assembly. Refer to page 12. NOTE: Micro Switch is Special and Should Not Be Substituted.
WS-503	1	Monitor Relay (Includes Jumpers) 60 FPM Units Only.
WS-504	1	Slipper
WS-505	1	Slipper Spring
WS-506	1	Jumper Harness — Numbered 21 & 22
WS-525	1	Motor (Frame & Stator, Shaft & Rotor, Items WS-527 and WS-529 Thru WS-537)
.....	1	Frame & Stator (Order Motor WS-525)
.....	1	Shaft & Rotor (Order Motor WS-525)
WS-528	1	End Bell and Plug
WS-529	4	Mounting Bolt and Lockwasher
WS-530	4	Mounting Bolt Lockwasher
WS-531	1	Bearing
WS-532	1	Bearing Snap Ring
WS-533	1	Bearing Retainer
WS-534	3	Bearing Retainer Screw
WS-535	3	Bearing Retainer Screw Lockwasher
WS-536	1	Thermal Overload Switch
WS-537	1	End Bell Expansion Plug
WS-545	1	Electric Brake (Items WS-546 Thru WS-554)
WS-546	1	Brake Base Plate With Studs
WS-547	2	Brake Friction Disc
WS-548	1	Brake Intermediate Plate
WS-549	1	Brake Armature With Plate & Shading Coils
WS-550	1	Brake Coil
WS-551	1	Brake Coil Retainer Strap
WS-552	1	Brake Field With Plate
WS-553	3	Brake Spring
WS-554	3	Brake Stud Nut
WS-555	2	Shading Coil
WS-575	1	Adjustable Screw Limit Switch (Items WS-55 see page 27, WS-576 Thru WS-594)
WS-576	1	Limit Switch Bracket With Bushing
WS-577	1	Limit Switch Bracket Bushing
WS-578	1	Limit Switch Shaft
WS-579	2	Limit Switch Shaft Nut
WS-580	1	Limit Switch Gear
WS-581	1	Limit Switch Gear Key
WS-582	1	Drum Cover Bushing
WS-583	1	Limit Switch Drive Pinion With Pin
WS-584	1	Drum Shaft Drive Pin
WS-585	1	Limit Switch Drive Pinion Attaching Screw
WS-586	1	Limit Switch Guide Screw
WS-587	1	Limit Switch Guide Screw Lockwasher
WS-588	2	Limit Switch
WS-589	4	Limit Switch Attaching Screw
WS-590	4	Limit Switch Attaching Screw Lockwasher
WS-591	4	Limit Switch Attaching Screw Nut
WS-592	2	Limit Switch Bracket Attaching Screw
WS-593	2	Limit Switch Bracket Attaching Screw Lockwasher
WS-594	2	Jumper Wire
WS-610	1	Reversing Contactor
WS-611	1	Speed Selecting Contactor
WS-645	1	Trolley Reversing Contactor
WS-785	1	Control Station

REFER TO PAGE 26 FOR ORDERING INSTRUCTIONS

Meteor Hoist Series SA

Parts List

Key No.	Req'd. No.	Part Name	Key No.	Req'd. No.	Part Name
WS-1	1	Gear Housing Cover	WS-99	8	Brake Housing Cover Screw
WS-2	2	Gear Housing Cover Dowell	WS-100	8	Brake Housing Cover Screw Lockwasher
WS-3	1	Gear Housing Cover Gasket	WS-111	1	Control Housing
WS-4	8	Gear Housing Cover Screw — 1¼" Lg.	WS-112	1	Control Housing & Limit Switch Housing Gasket
WS-5	2	Gear Housing Cover Screw — 1½" Lg.	WS-112	2	Control Housing & Limit Switch Housing Gasket (Weatherproof Hoist Only)
WS-6	1	Gear Housing	WS-113	5	Control Housing Screw
WS-7	1	Oil Filler Plug	WS-114	5	Control Housing Screw Lockwasher
WS-8	1	Oil Level Plug	WS-115	1	Control Housing Cover
WS-9	1	Oil Drain Plug	WS-116	1	Control Housing Cover Gasket
WS-10	1	Motor Shaft Oil Seal	WS-116	2	Control Housing Cover Gasket (Weatherproof Hoist Only)
WS-11	1	Motor Shaft Ball Bearing	WS-117	4	Control Housing Cover Screw
WS-12	2	Primary Intermediate Gear & Pinion Ball Bearing	WS-118	4	Control Housing Cover Screw Lockwasher
WS-13	1	Secondary Intermediate Gear & Pinion Ball Bearing — Cover End	WS-119	2	Conduit Retaining Screw
WS-14	1	Secondary Intermediate Gear & Pinion Ball Bearing — Housing End	WS-120	2	Conduit Retaining Screw Washer
WS-15	1	Drum Shaft Ball Bearing	WS-121	2	Conduit Retaining Screw Lockwasher
WS-16	1	Motor Pinion	WS-122	1	Conduit Packing Flange
WS-17	1	Primary Intermediate Gear & Pinion	WS-123	2	Packing Flange Screw
WS-18	1	Secondary Intermediate Gear & Pinion	WS-124	2	Packing Flange Screw Lockwasher
WS-19	1	Drum Gear	WS-125	1	Control Housing Plug (Not Shown) (Weatherproof Hoist Only)
WS-20	1	Motor Pinion Key	WS-126	1	Brake Lead Grommet
WS-21	1	Motor Shaft Snap Ring	WS-127	1	Transformer
WS-22	1	Drum Shaft Snap Ring	WS-128	2	Transformer Spacer
WS-39	1	Warning Label	WS-129	2	Transformer Attaching Screw
WS-40	1	Frame With Motor Cover Pins (Includes WS-39)	WS-130	2	Transformer Attaching Screw Lockwasher
WS-41	4	Frame Screw	WS-131	1	Terminal Board
WS-42	2	Frame Screw Lockwasher	WS-132	4	Terminal Board Spacer
WS-43	1	Motor Cover	WS-133	4	Terminal Board Mounting Screw
WS-44	2	Motor Cover Pin	WS-134	4	Terminal Board Mounting Screw Nut
WS-45	2	Motor Cover Clamp Screw	WS-135	4	Terminal Board Mounting Screw Lockwasher
WS-46	2	Motor Cover Clamp Screw Lockwasher	WS-136	3	Contacting Attaching Screw With Lockwasher
WS-47	1	Drum Shroud	WS-138	3	Control Housing Plug Screw #8-3UNC x ¾" Lg.
WS-48	4	Drum Shroud Attaching Screw	WS-139	3	Control Housing Plug Screw #10-32UNF x ¾" Lg. (Not Shown)
WS-49	1	Drum Shaft Oil Seal	WS-140	2	Limit Switch Housing Screw
WS-50	1	Gear Housing Dowel O-Ring	WS-141	2	Limit Switch Housing Screw Lockwasher
WS-51	1	Gear Housing Dowel	WS-142	1	Jumper Harness — Numbered 1, 2, 3
WS-52	1	Drum With Rope Anchor Insert & Screw	WS-143	1	Jumper Harness — Numbered 4, 5, 6
WS-53	1	Rope Anchor Insert	WS-144	1	Jumper Harness — Numbered 12, 13
WS-54	1	Rope Anchor Insert Screw	WS-145	1	Jumper Harness — Numbered 7, 8
WS-55	1	Drum Cover (Specify if unit is equipped with screw limits)	WS-146	1	Jumper — Numbered 14
WS-56	6	Drum Cover Screw	WS-148	1	Jumper Harness — Numbered 9, 10 & 11
WS-57	6	Drum Cover Screw Lockwasher	WS-149	1	Jumper — Numbered 15
WS-58	1	Drum Shaft Ball Bearing	WS-151	1	Jumper — Numbered 20
WS-59	1	Drum Cover Snap Ring	WS-153	3	Contacting Jumper — Black, ¼" Lg.
WS-60	1	Hoist Identification Plate	WS-160	1	Power Cable Connector
WS-61	4	Identification Plate Attaching Screw	WS-161	1	Power Cable
WS-62	1	Wiring Conduit	WS-162	1	Control Station Cord Connector
WS-63	2	Packing Ring	WS-177	1	Hoisting Rope With End Fittings
WS-64	1	Control Station Chain Attaching Link	WS-183	1	Dead End Spool Screw
WS-65	1	Control Station Chain Attaching Screw	WS-184	1	Dead End Spool Screw Lockwasher
WS-66	1	Control Station Chain Attaching Screw Lockwasher	WS-185	1	Hook Block Assembly (Items WS-186 Thru WS-200)
WS-67	1	Control Station Chain Attaching Screw Nut	WS-186	2	Hook Block Cover
WS-68		Control Station Chain (Specify Length Req'd.)	WS-187	2	Hook Block Cover Screw
WS-69		Control Station Cord (Specify Length Req'd.)	WS-188	2	Hook Block Cover Screw Lockwasher
WS-70	1	Motor Brake Hub Snap Ring — Inboard	WS-189 *	1	Hook Block Yoke
WS-71	1	Motor Brake Hub	WS-189 Δ	1	Hook Block Yoke With Shaft
WS-72	1	Motor Brake Hub Snap Ring — Outboard	WS-190	1	Hook Block Sheave Shaft
WS-73	4	Motor Brake Attaching Screw Lockwasher	WS-191 *	1	Hook Block Sheave
WS-74	4	Motor Brake Attaching Screw	WS-191 Δ	2	Hook Block Sheave
WS-83	1	Cable Return Ring With Screws and Lockwashers (Not Shown)	WS-191 Δ	1	Idler Sheave
WS-84	2	Cable Return Ring Screw (Not Shown)	WS-191 ∑	3	Hook Block Sheave
WS-86	2	Cable Return Ring Set Screw (Not Shown)	WS-191 ∑	2	Idler Sheave
WS-90		Control Station Cable Clip (Specify Number Req'd.)	WS-192	2	Hook Block Sheave Spacer
WS-92	4	Brake & Housing Attaching Screw	WS-193 *	1	Hook Block Sheave Ball Bearing
WS-93	1	Brake Base Plate Gasket (Weatherproof Hoist Only)	WS-193 Δ	2	Hook Block Sheave Ball Bearing
WS-94	1	Brake Housing Gasket	WS-193 Δ	1	Idler Sheave Ball Bearing
WS-95	1	Brake Housing	WS-193 ∑	3	Hook Block Sheave Ball Bearing
WS-96	3	Brake Housing Plug	WS-193 ∑	2	Idler Sheave Ball Bearing
WS-97	2	Brake Housing Cover Gasket	WS-194 *	1	Hook Block Sheave Bearing Washer
WS-98	2	Brake Housing Cover			



Exploded View Meteor Hoist Series SA

ADDITIONAL COMPONENTS FOR HOIST WITH MOTOR DRIVE TROUBLE

Key No.	No. Req'd.	Part Name	Key No.	No. Req'd.	Part Name
WS-454	1	Contacto Box, Cover, Gasket and Screws	WS-675	1	Motor and Pin (Frame & Stator, Shaft & Rotor, Items WS-678 Thru WS-688 & WS-415)
WS-456	3	Contacto Box Attaching Screw		1	Frame and Stator (Order Motor WS-675)
WS-457	3	Contacto Box Attaching Screw Lockwasher		1	Shaft and Rotor (Order Motor WS-675)
WS-458	2	Contacto Box Cover Attaching Screw	WS-678	1	End Bell (Pulley End)
WS-470	1	Power Cable (To Line)	WS-679	1	Spring Washer
WS-471	1	Power Cable (Contacto Box to Hoist)	WS-680	1	Bearing (Pulley End)
WS-472		Control Station Cord (Specify Length Req'd.)	WS-681	1	End Bell (Brake End)
WS-473	3	Contacto Attaching Screw	WS-682	1	Bearing (Brake End)
WS-474	3	Contacto Attaching Screw Lockwasher	WS-683	1	Snap Ring
WS-475	3	Contacto Attaching Screw Nut	WS-684	1	Bearing Cap
WS-476	1	Transformer	WS-685	4	Bearing Cap Screw
WS-477	2	Transformer Attaching Screw	WS-686	4	Motor Thru Bolt With Lockwasher
WS-478	2	Transformer Attaching Screw Lockwasher	WS-687	4	Motor Thru Bolt Lockwasher
WS-479	2	Transformer Attaching Screw Nut	WS-688	1	Brake Lead Grommet
WS-480	2	Power Cable Connector, O-Ring, and Locknut	WS-700	1	Trolley Motor Brake (Items WS-430 Thru WS-433, WS-435, WS-436 & WS-701)
WS-482	1	Control Station Cord Connector, O-Ring, and Locknut	WS-701	1	Electric Brake (Items WS-702 Thru WS-710)
WS-483	1	Control Station Cord Connector, O-Ring, and Locknut	WS-702	1	Brake Base Plate With Studs
WS-484*	1	Plug and Body (Power Cable to Hoist)	WS-703	1	Brake Friction Disc
WS-485*	1	Plug and Body (Control Station Cord to Hoist)	WS-704	1	Brake Armature With Plate
WS-488	1	Control Station Cord (Contacto Box to Hoist)	WS-705	1	Brake Coil
WS-489	4	Control Station Cable Connector	WS-706	1	Brake Coil Retainer Strap
WS-490	1	Transformer Lead Connector (460 Volt Unit Only)	WS-707	1	Brake Field With Plate and Shading Coils
WS-491	1	Control Station Chain Eyebolt	WS-708	2	Brake Spring
WS-492	2	Control Station Chain Eyebolt Washer	WS-709	10	Brake Spacer Washer
WS-493	2	Control Station Chain Eyebolt Nut	WS-710	2	Brake Stud Nut
WS-494	2	Ground Screw	WS-711	2	Shading Coil
WS-495	2	Ground Screw Lockwasher	WS-785	1	Control Station (See Page 36)
WS-496	2	Ground Screw Nut	WS-784	1	Push Button Box Connector
WS-497		Motor Lead Connector (1 Req'd. for 230V. Unit) (3 Req'd. for 460V. Unit)	WS-785	1	2-Push Button Station Discontinued — Control Station Page 35 will be furnished
WS-645	1	Trolley Reversing Contacto	WS-785	1	4-Push Button Station Discontinued — Control Station Page 36 will be furnished

*Discontinued for repairs only.

Note: The Terminal Box and associated parts shown on the opposite page as mounting on side of motor, plus the additional control parts shown mounting on Control Panel are for a Hoist with Single Speed Trolley.


REFER TO PAGE 26 FOR ORDERING INSTRUCTIONS

Plain, Geared and Motor Driven Trolleys

Parts List

Key No.	No. Req'd.	Part Name	Key No.	No. Req'd.	Part Name
WS-64	2	Control Station Chain Attaching Link	WS-401	1	Idler Sheave Housing Support Pin Keeper Plate Screw Lockwasher (For 5 Ton Capacity Only)
WS-68		Control Station Chain (Specify Length Req'd.)	WS-402		Trackwheel Pinion Spacer Washer (3 Ton Only—Specify No. Req'd.) (Not Shown)
W WS-90		Control Station Cord Clip (Specify No. Req'd.)			
WS-153	3	Contacto Jumper	WS-403	1	Trackwheel Pinion Shaft
WS-326	2	Hoist Suspension Bolt	WS-404	1	Trackwheel Pinion Lockwasher
WS-327	4	Hoist Suspension Bolt Nut	WS-405	1	Trackwheel Pinion Nut
WS-328	4	Hoist Suspension Bolt Nut Cotter Pin	WS-406	1	Trackwheel Pinion Spacer
WS-330	52	Spacer Washer (For 1/2-2 Ton Capacity)	WS-407	1	Pinion Bearing Sleeve
WS-330	36	Spacer Washer (For 3 Ton Capacity)	WS-408	2	Pinion Shaft Ball Bearing
WS-330	32	Spacer Washer (For 5 Ton Capacity)	WS-409	1	Intermediate Shaft Ball Bearing (Side Frame End)
WS-370	4	Trackwheel With Bearing Cups	WS-410	1	Intermediate Shaft Ball Bearing (Motor End)
WS-371	8	Trackwheel Bearing Cup	WS-411	1	Driven Gear
WS-372	8	Trackwheel Bearing Cone	WS-412	1	Intermediate Pinion
WS-373	8	Trackwheel Bearing Seal Washer	WS-413	1	Intermediate Gear
WS-374	4	Trackwheel Stud	WS-414	1	Motor Pinion And Pin
WS-375	4	Trackwheel Stud Collar	WS-415	1	Motor Pinion Pin
WS-376	4	Trackwheel Stud Nut	WS-416	1	Driven Gear Key
WS-377	2	Trackwheel Gear And Pins	WS-417	1	Pinion Bearing Spacer
WS-378	4	Trackwheel Gear Pin	WS-418	1	Intermediate Bearing Spacer
WS-379	1	Trackwheel Gear Pinion	WS-419	1	Intermediate Pinion Nut
WS-380	1	Trackwheel Pinion Key	WS-420	1	Intermediate Pinion Nut Lockwasher
WS-381	1	Geared Side Frame (Does Not Include Wheels)	WS-421	1	Gear Housing
WS-382		Plain Side Frame (Does Not Include Wheels)	WS-422	1	Gear Housing Gasket
		1 Req'd. for Geared & Motor Driven Trolleys	WS-423	4	Gear Housing Screw
		2 Req'd. for Plain Trolley	WS-424	4	Gear Housing Screw Lockwasher
WS-383	1	Handwheel Bracket With Bushings	WS-425	1	Motor End Bell Gasket
WS-384	2	Handwheel Bracket Bushing	WS-430	1	Brake Hub
WS-385	3	Handwheel Bracket Screw Lockwasher	WS-431	1	Brake Hub Snap Ring
WS-386	3	Handwheel Bracket Screw	WS-432	2	Brake Attaching Screw
WS-387	1	Handwheel Shaft	WS-433	2	Brake Attaching Screw Lockwasher
WS-388	1	Hand Chain Wheel Key	WS-434	2	Brake or Motor Cover Gasket (Weatherproof Units Only)
WS-389	1	Hand Chain Wheel	WS-435	1	Brake Cover
WS-390	2	Handwheel Shaft Nut Lockwasher	WS-436	3	Brake Cover Screw
WS-391	2	Handwheel Shaft Nut	WS-437	3	Brake Cover Screw Lockwasher
WS-392	1	Hand Chain Guide	WS-438	1	Motor End Cover
WS-393	1	Chain Guide Screw	WS-439	3	Motor End Cover Screw
WS-394	1	Chain Guide Screw Washer	WS-440	3	Motor End Cover Screw Lockwasher
WS-395	1	Chain Guide Screw Nut Lockwasher	WS-441	1	Terminal Box
WS-396	1	Chain Guide Screw Nut	WS-441	1	Terminal Box, Cover & Gasket (Weatherproof Unit Only) (Not Shown)
WS-397		Hand Chain And Connecting Link (Specify Length Req'd.)	WS-442	1	Terminal Box Cover
WS-398	1	Hand Chain Connecting Link	WS-443	1	Terminal Board
WS-399	1	Idler Sheave Housing Support Pin Keeper Plate (For 5 Ton Capacity Only)	WS-444	1	Terminal Box Attaching Screw
WS-400	1	Idler Sheave Housing Support Pin Keeper Plate Screw (For 5 Ton Capacity Only)	WS-445	1	Terminal Box Attaching Screw Lockwasher
			WS-446	2	Terminal Board Spacer
			WS-447	2	Terminal Box & Board Attaching Screw
			WS-448	2	Terminal Box & Board Attaching Screw Lockwasher
			WS-450	1	Power Cable Connector
			WS-451	1	Power Cable
			WS-453	1	Junction Box Gasket

**Exploded View - Trolley Components
For Meteor Hoist SA**



**Separate Motor Driven Trolley
Control Components**


Motor Driven Trolley Motor Brake

Motor Driven Trolley

METEOR HOIST MONITOR IDENTIFICATION COLOR CODE

MODEL	5842 5842-2 5814 5814-2 5834 5834-2	5862 5862-2	5843 5843-2 5815 5815-2 5835 5835-2	5863 5863-2	5844 5844-2 5826 5826-2 5836 5836-2	5864 5864-2	5845 5845-2 5827 5827-2	5830 5830-2
COLOR CODE	BLACK	ORANGE	YELLOW	PURPLE	RED	WHITE	GREEN	BLUE

SECTION D – TROUBLE SHOOTING
All Hoists

IF	CAUSE MAY BE	REMEDY						
1) Hook does not raise or lower	a) No voltage at hoist	Main line or branch circuit switch open; branch line fuse blown or circuit breaker tripped. Close, replace or re-set. Grounded or faulty connection in supply lines or current collectors.						
	b) Phase failure (Single phasing)	Open circuit, grounded or faulty connection in one line of supply system, collectors, hoist wiring, reversing contactor, motor leads or windings. Check for electrical continuity.						
	c) Open control circuit	Open or shorted winding in transformer or reversing contactor coil; loose connection or broken wire in circuit; mechanical binding in contactor; control station contacts not making. Check continuity and repair or replace defective parts.						
	d) Wrong voltage or frequency	The voltage and frequency must be the same as shown on hoist identification plate.						
	e) Low voltage	Read voltage at the plug end of hoist power cable while operating hoist in  UP direction with full load. Reading should be as follows:						
		<table border="0"> <tr> <td align="center">UNIT RATING</td> <td align="center">MINIMUM VOLTAGE</td> </tr> <tr> <td align="center">208-240/3/60</td> <td align="center">187</td> </tr> <tr> <td align="center">440-460/3/60</td> <td align="center">396</td> </tr> </table>	UNIT RATING	MINIMUM VOLTAGE	208-240/3/60	187	440-460/3/60	396
	UNIT RATING	MINIMUM VOLTAGE						
208-240/3/60	187							
440-460/3/60	396							
f) Brake not releasing	Branch line overloaded, install separate line to hoist or use proper wire size for branch line. Open or shorted coil winding; open wiring harness circuit. Check continuity and repair or replace defective part. Armature binding; brake not properly adjusted. See Page 12.							
g) Excessive load	Reduce loading to the capacity limit of hoist as indicated on the identification plate.							
2) Hook moves in the wrong direction	a) Phase reversal	See Page 3.						
	b) Reverse winding of rope	Rope has been wound on wrong side of drum. Rewind and check rope for damage.						
3) Hook lowers but will not raise	a) Excessive load	Reduce loading to the capacity limit of the hoist as indicated on the identification plate.						
	b) Open hoisting circuit	Open or defective motor thermal switch. Switch automatically resets when motor has cooled sufficiently to resume operation, in approximately one hour. Check continuity in the switch after motor has cooled and replace if it shows an open circuit. Open or shorted winding in reversing contactor coil; loose connection or broken wire in hoisting circuit; control station contacts not making.						

Adjustments (Cont'd)

rope anchor through switch assembly, insert anchor bushing in Monitor assembly, seat rope anchor into bushing recess, allow assembly to seat against anchor plate by releasing grasp on rope anchor.

Pull rope until end anchor seats properly on the underside of Monitor assembly.

Check to be sure everything is properly seated and that Monitor is properly nested in its protected position between the z-bars of the hoist frame.

Tighten up dead end spool screw. Be sure that screw is not binding on rope.

Place sheaves, assembled on hook block sheave shaft, on the lower loops of rope.

Install hook block side plates over sheave shaft and hook block trunnion.

With hook block spacers in position, slide hook block bolts through capacity plates, side plates and spacers.

Lock in position with nuts.

8. Place the two halves of limit switch weight

around rope just below dead end spool. Lock in position with screws. Limit switch weight must be free to slide on rope.

9. Check rope to make sure there are no twists. Twists can be removed as follows:
 - a) Operate the lowering control until hook has reached its lower limit of travel. There should be at least 2 wraps of rope remaining on drum.
 - b) Disconnect hoist from power supply.
 - c) Now pull the dead end of hoisting rope downward until the hook is within several feet of bottom of hoist.
 - d) Then return hoisting rope to its operating position making sure the rope anchor is seated properly on the underside of anchor bushing, and Monitor assembly.
 - e) Repeat above pulling on the dead end if twist remains. While pulling, a twisting motion imparted to the dead end fitting by hand will expedite removal of hoisting rope twists.

Instructions For Installing Meteor Monitor

1. Disconnect lower hook from any loads, disconnect power supply, remove motor cover.
2. Remove dead end spool screw and lockwasher. Slide molded slipper between wire rope and dead end spool until slot in slipper is centered over screw hole, slot should be open toward motor. Slide slipper spring over dead end spool screw and lockwasher. Re-install screw so that the tangs of the spring fit into the grooves in the slipper and tighten screw securely. Refer to Fig. 4.
3. **Do Not Take Switch Assembly Apart.** Grasp the dead end rope anchor and pull down several inches of wire rope. Thread rope anchor through switch assembly, insert anchor bushing in Monitor assembly, seat rope anchor into bushing recess, allow assembly to seat against anchor plate by releasing grasp on rope anchor. Check to be sure everything is properly seated and that Monitor is properly nested in its protected position between the z-bars of the hoist frame. Refer to Fig. 4.
4. Run Monitor leads along inboard side of motor power conduit and secure leads with two cable ties. (This step should be omitted on 5-ton model hoists).
5. Remove control housing covers, remove rubber brake lead grommet. Pass Monitor leads through grommet hole, slip grommet over the four brake and Monitor leads and install grommet in control housing. Seal wires passing through grommet by forcing Silastic, RTV, Permatex, glazing compound or other non-hardening sealant between wires and into grommet.

6. Mount the relay using the screw and sealing washer. Be sure locating boss on relay rests in drilled hole. Connect relay per wiring diagram. (60 FPM units only).
7. Re-assemble control housing cover and gasket, re-assemble motor cover.
8. Operate hoist in "down" direction (to energize relay on 60 FPM unit) and then check for proper hoist operation under no load condition.

NOTE:

1. Although the Monitor is weather resistant, it is not recommended for use in severe acid environments.
2. Do not disassemble or re-calibrate the Monitor Assembly.
3. Check color code on chart Page 16 to make sure Monitor is for proper hoist model.





FIGURE 4

Adjustments (Cont'd)

3. Remove dead end spool screw, lockwasher, and slipper spring. Grasp the dead end rope anchor and pull down several inches of wire rope. Remove anchor bushing and pull anchor through Monitor assembly. Slide molded slipper and wire rope out of slot and off of dead end spool.
4. Using heavy canvas or leather gloves, operate hoist in the lowering direction keeping the rope under tension until it is completely unwound from drum.
5. Unscrew drum anchor insert screw and re-thread it into the tapped hole in drum anchor insert to provide a grip for removing the insert.
6. Pry out insert and withdraw the rope end.

INSTALLING ROPE

1. Uncoil the rope and straighten it out along the floor to remove all twists. Keep rope clean.
2. Insert rope end anchor into hole in drum.
3. Move rope sideways into slot. A straight pull on rope should not release it.
4. Secure rope in this position with drum anchor insert.
5. Lock insert in place with screw.
6. Wind the rope on drum under tension, by operating  UP Control, leaving about 10 feet hanging for two-part rope, about 15 feet for four-part rope and about 20 feet for six-part rope.
7. **Two-part rope unit**

Loop the end of rope over dead end spool while sliding molded slipper between wire rope and dead end spool until slot in slipper is centered over screw hole, slot should be open toward motor. Slide slipper spring over dead end spool screw and lockwasher. Re-install screw so that the tangs of the spring fit into the grooves in the slipper.

Grasp the dead end rope anchor and pull down several inches of wire rope. Thread rope anchor through switch assembly, insert anchor bushing in Monitor assembly, seat rope anchor into bushing recess, allow assembly to seat against anchor plate by releasing grasp on rope anchor.

Pull rope until end anchor seats properly on the underside of Monitor assembly.

Check to be sure everything is properly seated and that Monitor is properly nested in its protected position between the z-bars of the hoist frame.

Tighten up dead end spool screw. Be sure that screw is not binding on rope.

Place hook block sheave on the rope.

Place sheave with two spacers in position into hook block yoke.

Insert sheave shaft.

Re-assemble covers.

Four-part rope unit

Make a three-foot loop in the rope in the counter-clockwise direction looking from motor side.

Place idler sheave in top of loop.

Insert sheave between the two plates hanging from z-bars. The free end of rope should be next to the side of sheave furthest from dead end spool.

Insert idler sheave shaft.

Lock in place with keeper plate.

Loop the end of rope over dead end spool while sliding molded slipper between wire rope and dead end spool until slot in slipper is centered over screw hole, slot should be open toward motor. Slide slipper spring over dead end spool screw and lockwasher. Re-install screw so that the tangs of the spring fit into the grooves in the slipper.

Grasp the dead end rope anchor and pull down several inches of wire rope. Thread rope anchor through switch assembly, insert anchor bushing in Monitor assembly, seat rope anchor into bushing recess, allow assembly to seat against anchor plate by releasing grasp on rope anchor.

Pull rope until end anchor seats properly on the underside of Monitor assembly.

Check to be sure everything is properly seated and that Monitor is properly nested in its protected position between the z-bars of the hoist frame.

Tighten up dead end spool screw. Be sure that screw is not binding on rope.

Place sheaves, assembled on hook block yoke and shaft, on the lower loops of rope.

When re-assembling covers, tighten each cover screw an equal amount to align the sheaves below the cover openings.

Six-part rope unit

Make two three-foot loops in the rope in the clockwise direction looking from motor side. Place two idler sheaves in the top of loops. Insert sheaves between sides of idler sheave housing in the same order the loops were made.

Insert idler sheave shaft through housing and sheaves.


Lock in place with keeper plate.

With idler sheave housing held under the hoist in approximate position, check the reeving of unit as shown in diagram on Page 13.

If correct, secure in position with idler sheave housing support pin.

Loop the end of rope over dead end spool while sliding molded slipper between wire rope and dead end spool until slot in slipper is centered over screw hole, slot should be open toward motor. Slide slipper spring over dead end spool screw and lockwasher. Re-install screw so that the tangs of the spring fit into the grooves in the slipper.

Grasp the dead end rope anchor and pull down several inches of wire rope. Thread



Adjustments (Cont'd)

HOISTING ROPE

Rope is furnished complete with assembled end fittings. The ends are interchangeable and the rope can be reversed to distribute wear and obtain longer life.

Refer to the following illustrations for assistance in removing and installing rope.

CAUTION: If replacement wire rope is not purchased from Columbus McKinnon Corporation, extreme care must be used in attaching the end fittings. Apply for further information. When removing or installing rope on hoists equipped with screw limit switch, first remove limit switch guide screw. After installation, then re-set limits.

REMOVING ROPE

1. Remove limit switch weight from rope.

2. Two-part rope hoist

Remove hook block covers.

Pull out sheave shaft.

Remove rope from sheave.

Four-part rope hoist

Remove hook block covers.

Remove rope from sheaves.

Remove idler sheave shaft keeper plate.

Push out idler sheave shaft.

Remove rope from sheave.

Six-part rope hoist

Remove hook block plates.

Remove rope from sheaves.

Remove idler sheave housing support pin allowing idler sheave housing to be removed from the hoist.

Remove idler sheave shaft keeper plate.

Push out idler sheave shaft.

Remove rope from sheaves.

Trolley Lubrication

GEARED TROLLEY

- Once a month lubricate trackwheel gears with Texaco Novatex No. 2 or an equivalent heavy cup grease or graphite grease.
- Every six months lubricate handwheel shaft bearings with 3-in-1 or light machine oil.

MOTOR DRIVEN TROLLEY

- Once a month lubricate trackwheel gears with Texaco Novatex No. 2 or an equivalent heavy cup grease or graphite grease.
- The motor bearings and reduction gears require no additional lubrication. However, if gears are disassembled upon reassembly use Texaco Novatex No. 1 or an equivalent medium cup grease.

Adjustments

ELECTRIC BRAKE ASSEMBLY

The correct air gap between armature and field, when brake is not energized, is 0.025 inch and need not be adjusted until the gap reaches 0.045 inch.

To adjust the brake, proceed as follows:

1. Disconnect hoist from power supply.
2. Remove motor cover.
3. Before adjusting the gap, back off the stud nuts and examine friction linings and friction surfaces for wear, scoring or warpage. Also check shading coils to be sure they are in place and not broken. A missing or broken shading coil will cause the brake to be noisy when hoist is operated.
On units having a weatherproof brake housing, remove the two rectangular covers on side of housing to check parts and measure air gap, and remove the three plugs in end of housing to reach adjusting nuts.
4. Turn adjusting nuts clockwise gaging the air gap at both ends.
5. Replace cover(s), reconnect the power and check operation.

UPPER LIMIT SWITCH

If switch operation has been checked as described on Page 3 and is not operating correctly, proceed as follows:

1. Disconnect hoist from power supply.
2. Remove control housing cover.
3. Lift limit switch weight slowly — a sharp click when cam lifts the roller of right hand switch indicates that the hoisting control circuit is interrupted. Continue to lift the weight and the left hand switch should click when its roller drops into the cam depression — indicating that the lowering circuit is energized to reverse motor.
4. If either or both switches fail to operate, loosen the two screws that hold the limit switches to bracket. Move right hand switch until the clearance between the cam and switch roller is 1/32 inch. Make sure left hand switch roller is in contact with its cam. Tighten screws, replace cover, reconnect the power and check operation.

LOWER HOOK

When replacing a hook, allow 1/8 inch clearance

between hook shoulder and bottom of hook yoke sub-assembly or hook trunnion.

ADJUSTABLE SCREW LIMIT SWITCH

To adjust hook travel, proceed as follows:

1. Disconnect hoist from power supply.
2. Remove control housing cover.
3. Withdraw guide screw from between limit switch nuts.
4. Turning the limit switch nut one notch changes hook position approximately 2 1/2 inches on two-part rope, 1 1/4 inches on four-part rope or 13/16 inch on six-part rope hoists.
Moving one nut toward the other increases hook travel and away from the other decreases the travel.
The nut nearest cover operates at upper hook position and the nut nearest hoist operates at lower limit of hook travel.
The screw limit switch should be adjusted so that at least 2 wraps of rope remain on the drum at the lower limit of travel.
5. Replace guide screw and cover. Reconnect the power and check operation.

MONITOR CALIBRATION

When Re-Calibration becomes necessary due to repair of the Monitor switch assembly proceed as follows:

1. After repairs are completed and hoist is re-assembled, place a load of 140% hoist capacity on unit.
2. Raise load approximately 1" off floor and adjust Monitor switch adjusting screw until switch operates and load cannot be raised.
3. Lower load, disconnect lower hook from load, and disconnect power supply.
4. Grasp the dead end rope anchor and pull down until Monitor adjusting screw is accessible. Apply Loctite 242 to adjusting screw at trip plate and let dry.

NOTE: The Meteor Monitor is intended to allow handling of rated loads. If, in the case of some high speed hoists, the above procedure prevents lifting a rated capacity load, the Monitor should be readjusted to permit handling the rated load.

at an angle. These edges should be smoothed and rounded.

- h) Inspect trolley trackwheels for external wear on the tread and flange, and for wear on internal bearing surfaces as evidenced by a looseness on the stud.
- i) Inspect the complete unit for wear or damage to adjacent parts, corrosion, loose fastenings, bent or cracked covers or housings, damaged wires or insulation, loose or dirty connections.
- j) Inspect collector shoes for wear. Badly worn parts should be replaced.

TESTING:

Prior to initial use, all altered or repaired hoists or used hoists that have not been operated for the previous 12 months shall be tested by the user for proper operation. Test the unit first in the unloaded state and then with a light load of 50 pounds times the number of load supporting parts of wire rope to be sure it operates properly and the brake holds the load when the control is released; then test with a load of * 125% of rated capacity.

In addition, hoists in which load sustaining parts have been replaced shall be tested with *

125% of rated capacity by or under the direction of an appointed person and a written report prepared for record purposes.

After this test, the function of the Monitor is to be tested. If the Monitor permits lifting a load in excess of 140% of rated load it should be adjusted as described on page 12.


NOTE: For additional information on inspection and testing, refer to Code B30.16 "Overhead Hoists," obtainable from American National Standards Institute, 1430 Broadway, New York, N. Y. 10018 U.S.A.

* If the Monitor prevents lifting of a load of 125% of rated capacity, reduce load to rated capacity.

HOOKS:

Hooks damaged from chemicals, deformations or cracks, or that have more than a 10 degree twist from the plane of the unbent hook or excessive opening or seat wear must be replaced.

Any hook that is twisted or has excessive throat opening indicates abuse or overloading of the unit. Other load sustaining components of the hoist should be inspected for damage.



HOOK USE	Unit Capacity Tons	Parts of Rope	Replace Hook When Opening or Seat Are:	
			"A" Max.	"B" Min.
LOWER	1/2—1 1/2	2	1 57/64	57/64
	1—3	4	2 15/32	1 3/16
	5	6	2 57/64	1 1/2
UPPER	1/2—5	—	2 15/32	1 3/16

Hoist Lubrication

GEARS

- Check oil level in gear housing at least once a month, maintaining it at the bottom of oil level hole in gear housing cover.
- Drain housing every 2-3 years and refill with a good grade of SAE 80 or 90 gear lubricating oil — 2 quarts are required.

BEARINGS

- All bearings except the lower hook thrust bearings are pre-lubricated or are in an oil bath and need no lubrication. The lower hook thrust bearing should be lubricated at least once a month.

WIRE ROPE

- A small amount of lubricant will greatly increase the life of hoisting rope, therefore, the rope should not be allowed to run dry.
- Keep it clean and lubricate at regular intervals

with a commercial wire rope lubricant or 600W oil. Under ordinary conditions, monthly lubrication is satisfactory but under hot and dirty conditions, it may be necessary to clean the hoisting rope at least once a day and lubricate it several times between cleanings.

- Particular attention should be directed to lubrication of the rope where it passes around the dead end spool as well as that section which passes over the sheaves.

LIMIT SWITCH ASSEMBLY

- Every six months remove the control housing cover and oil the limit switch cam shaft, cams and switch rollers using 3-in-1 or light machine oil.
- If hoist is equipped with an adjustable screw limit switch, oil the screw, bushings at each end, gear teeth and switch rollers.

SECTION C – MAINTENANCE

Inspection

To maintain continuous and satisfactory operation, a regular inspection procedure must be initiated so that worn or damaged parts can be replaced before they become unsafe. The intervals of inspection must be determined by the individual application and are based upon the type of service to which the hoist will be subjected and the nature of the critical components and the degree of their exposure to wear, deterioration or malfunction. The inspection of hoists is divided into two general classifications designated as "frequent" and "periodic."

The type of service to which the hoist is subjected can be classified as "Normal," "Heavy," and "Severe."

Normal service involves operating the hoist at less than 85% of its rated capacity and not more than 10 lift cycles per hour, except for isolated instances.

Heavy service involves operating the hoist at 85% to 100% of rated capacity or in excess of 10 lift cycles per hour as a regular specified procedure.

Severe service is normal or heavy service coupled with the possibility of abnormal, unforeseen conditions.

Below is the recommended, minimum intervals of inspection. When the unit is subjected to extra heavy usage or dusty, gritty, moist, or other adverse atmospheric conditions, shorter time intervals must be assigned. During the Periodic Inspection, inspection must be made of all parts for unusual wear, corrosion effect, or damage, in addition to those specifically mentioned.

Any deficiencies noted are to be corrected before the hoist is put into service.

Periodic Inspection & Maintenance Procedure

CAUTION: The outboard bearings supporting the intermediate gears are located in gear housing cover, therefore, it should be carefully removed.

It is suggested, in order to retain the gears in gear housing, that the hoist be tipped slightly upward or positioned on end, then carefully lift cover.

A small wedge should be inserted between hoist drum and frame to prevent the hoisting rope from unreeling, in case any of the gears are removed during or after cover removal.

Minimum Inspection Schedule

FREQUENT INSPECTIONS:

These inspections are usually visual examinations by the operator or other designated personnel and records of such inspections are not required. For Normal, Heavy and Severe Service, the frequent inspections are to be performed daily or monthly and shall include the following items:

- a) Brake for evidence of slippage — daily.
- b) Limit switches for proper operation — daily (refer to page 3).
- c) Inspect hoisting rope for kinks, crushed strands, frayed or broken wires and corrosion — daily (refer to page 11).
- d) Hooks for damage, cracks, twists, excessive opening, latch engagement and latch operation — daily (refer to chart on page 11).

PERIODIC INSPECTIONS:

These inspections are visual inspections of external conditions by an appointed person and rec-

ords of periodic inspections are to be kept to provide the basis for continuing evaluation of the condition of the hoist. For Normal and Heavy Service, the periodic inspections are to be performed yearly with the hoist in place. For Severe Service, the periodic inspections are to be performed quarterly.

Periodic Inspections are to include those items listed under frequent inspections as well as the following:

- a) Check upper limit switch for operation as described on Page 3.
- b) Inspect contactor(s) and control station for burnt or pitted contacts and loose or corroded terminals.
- c) Inspect control station cord and power cables for damaged wires or insulation.
- d) Check oil level in gear housing as described on Page 3.
- e) Inspect electric brake friction linings and friction surfaces for wear, scoring or warpage. Check air gap between armature and field and if the gap exceeds 0.045 inch adjust as described on Page 12.
- f) Inspect sheaves for wear — a deepening and narrowing of the groove, which causes pinching and severe abrasion of hoisting rope; spiral ridges or flutes in bottom of groove which cause chafing of the rope. This can be corrected by machining the sheave groove until the ridges are removed using a 3/16 inch radius cutter. Replace sheave when groove diameter has been reduced to 5½ inches.
- g) Inspect hoisting rope drum for burrs or sharp edges between grooves, caused by pulling loads

4. The control station used on two speed hoist is similar to the single speed unit, except that either of two definite speeds may be selected by the operator in both hoisting and lowering. Each control when partially depressed provides **slow** speed and when fully depressed gives **fast** speed. Partial release of control returns hoist to **slow** speed, while full release allows hoist to stop. Rated lifting speeds are shown on hoist identification plate.

Slow speed is intended as a means of carefully controlling or "spotting" the load, although the

hoist may be operated solely at this speed if desired. It is not necessary to operate in the **slow** speed position as the hoist will pick up a capacity load at **fast** speed from a standing start. In other words, it is not necessary to hesitate at the **slow** position when moving control from **Stop** to **Fast** position or vice versa.

5. If material being handled must be immersed in water, pickling baths, any liquid, dusty or loose solids, use a sling chain of ample length so that the hook is always above the surface. Bearings in the hook block are shielded only against ordinary atmospheric conditions.

Operating Instructions

HOIST

1. Before picking up a load, check to see that the hoist is directly overhead and that the hoisting rope is properly arranged in drum grooves. If rope has been displaced, unwind it as far as necessary and rewind correctly.
2. The hoist is designed to raise a load vertically and should not be used for pulling at an angle. **When applying a load it should be directly under hoist or trolley. Avoid off center loading of any kind.** Pulling to the side causes tipping of hoist, allows hoisting rope to foul upper limit switch and to chafe against hoist frame. Pulling toward the end permits rope to climb out of drum grooves and overwind at one end, causing severe chafing and wear to the rope. Trolley mounted hoists may jump suddenly along runway beam if the load is not directly beneath hoist when slack is taken up.
3. Take up a slack rope carefully and start load easily to avoid shock and jerking of hoist ropes. If there is any evidence of overloading, immediately lower the load and remove the excess load.
4. Do not allow the load to swing while hoisting as rope will not wind properly on drum.
5. When hook is lowered the full length of its rated lift, there are at least 2 wraps of rope remaining on drum. The hook must not be lowered beyond this point unless load is re-

moved. Continued operation with lowering control depressed after hook reaches the lowest position causes hook to raise by winding the rope onto reverse side of drum. Severe damage to rope occurs by chafing against hoist frame; upper limit switch will be inoperative and will cause breaking of hoisting rope or burning out of motor when the hook block reaches it. **The rope must always wind on and off drum on the side nearest hoist motor—never on the outside.**

HOIST WITH PLAIN TROLLEY

This unit should be moved by pushing on the suspended load or by pulling the empty hook. The pendant chain supporting control station should not be used for this purpose.

HOIST WITH GEARED TROLLEY


This unit should be moved by means of the pendant hand chain. Pull on the chain farthest from end toward which the unit is to travel.

HOIST WITH MOTOR DRIVEN TROLLEY

This unit should be moved by operating the controls marked **◆ FORWARD** and **◆ REVERSE** in control station. Unless altered by the erector, depressing **◆ FORWARD** control will move hoist toward gear housing end. Anticipate the stopping point and allow trolley to coast to a smooth stop. Reversing or "plugging" to stop trolley causes overheating of motor and swaying of load.

Safety Procedures

1. When preparing to lift a load, be sure that the attachments to the hook are firmly seated in hook saddle. Avoid off center loading of any kind, especially loading on the point of hook.
2. When lifting, raise the load only enough to clear the floor or support and check to be sure brake will hold the load and that the attachments to hook and load are firmly seated. Continue lift only after you are assured the load is free of all obstructions.
3. Do not load hoist beyond the rated capacity shown on hoist identification plate and on lower hook block. Overload can cause immediate failure of some load carrying part or create a defect causing future failure at less than rated capacity. When in doubt, use the next larger capacity of CM Meteor Hoist.
4. Do not use this or any other overhead **materials** handling equipment for lifting persons.
5. Stand clear of all loads and avoid moving a load over the heads of other personnel. Warn personnel of your intention to move a load in their area.
6. Do not leave the load suspended in the air unattended.
7. Permit only qualified personnel to operate unit.



*If conductor system includes transfer guides, conductors are spaced at 3" apart.

ALTERNATE METHODS OF WIRING

A flexible conductor cable can be used to supply power to a trolley mounted hoist. The length of conductor should be adequate for the full travel of trolley. A long conductor will usually require a clamp or strain relief (available from factory)

CAUTION: Trolley beam should always be electrically grounded. Be sure that there is good electrical contact between trolley beam and track-wheels. Avoid the use of paint or other coatings on the beam flange which might form an insulation.




FIGURE 3

fitting at the hoist to prevent kinking where the conductor enters hoist. To keep the slack conductor away from the hoist and load, a messenger wire system, a counterweighted pulley or a spring loaded cord reel (available from manufacturer) can be used.

Adjustable Screw Limit Switch

This optional equipment device, if factory installed, is set for nearly full hook travel. If it is necessary to change the setting, instructions are given in Section C.

Where this device has been purchased separately, refer to the instructions packed with device.

SECTION B – OPERATION

General

1. The CM Meteor Monitor is designed to protect the Meteor Hoist from excessive, infrequent overloads. The device provides safety and protects against motor burnout.
CAUTION: The Monitor is not intended to be used as a scaling device for purposes of determining what is an appropriate or safe load to be lifted on a regular basis.
 A make-before-break relay is required in the high speed (60 FPM) Meteors.
 The hoist will not operate in the hoisting direction unless the relay is energized. The relay, however, does not affect lowering, and the hoist will always lower. Pushing the "DOWN" control energizes the relay and closes the relay-maintain circuit which keeps the relay energized after the "DOWN" control is released. When a hoist overload trips the Monitor switch, this opens the relay-maintain circuit, making the hoist inoperable in the up direction. To restore the circuit, the overload must be lowered to the floor to reset the Monitor switch. Pushing the "DOWN" control to lower the load also resets the relay, once the Monitor switch resets.
NOTE: It is only necessary to energize the hoist in the down direction at initial "start-up"

- or in the event of an overload. It is not necessary to depress the DOWN control each time the hoist is operated.
2. The hoist is equipped with an upper limit switch which opens the hoisting circuit. If hoist does not halt promptly, a second limit switch momentarily reverses the motor to stop the hook positively. This protection exists only when the power supply to the motor is correctly phased. On hoists equipped with the adjustable screw limit switch, this device automatically stops hook at any predetermined point in either hoisting or lowering and does not, in any way, affect the operation of upper limit switch. As above, this protection exists only when the power supply to motor is correctly phased.
3. The hoist motor normally is equipped with a thermal protection switch, which interrupts the hoisting operation when motor reaches its maximum safe temperature. If this switch opens while a load is suspended from hoist, the hook may be lowered to remove the load while motor is cooling off. The thermal switch automatically resets when motor has cooled sufficiently to resume operation, in approximately one hour under normal conditions.


Motor Driven Trolleys

The motor driven trolley is shipped assembled and wired to the hoist, however, spacing of trackwheels for the actual beam the unit is to be installed on must be checked.

Before operating trolley, lubricate trackwheel gears with Texaco Novatex No. 2 or an equivalent heavy cup grease or graphite grease.

The motor driven trolley is wired in such a way that when the hoist motor is operating correctly, as described on Page 3, the trolley will move toward the gear housing end when **FORWARD** control is depressed.

IMPORTANT ADJUSTMENT INSTRUCTIONS METEOR TROLLEYS



THE NUMBER OF WASHERS SHOWN BELOW IS NOMINALLY CORRECT. DUE TO VARIATIONS IN SIZE ENCOUNTERED ON STRUCTURAL STEEL SECTIONS, IT WILL BE NECESSARY IN SOME CASES TO VARY THE NUMBERS USED. THE DISTANCE BETWEEN TRACKWHEEL FLANGES SHOULD BE 1/8 TO 3/16 GREATER THAN THE BEAM FLANGE. WHEN USED ON MONORAIL WITH CURVES LIGHTLY LUBRICATE EDGES OF BEAM AT CURVE SECTION WITH GREASE. **WARNING: SPECIAL TROLLEYS IN CHART REQUIRE SPECIAL SIDE FRAMES AND SUSPENSION BOLTS.**

With a capacity load on hoist, operate trolley over the entire length of runway or monorail system to be sure that the adjustment and operation is satisfactory.

For Separate Motor Driven Trolley (trolley shipped separately from hoist), refer to the instructions packed with unit and the information given above.

	AMER. STD. FLANGE WIDTH	1/2 TO 2 TON				3 TON				5 TON			
		A	B	C	D	A	B	C	D	A	B	C	D
STANDARD TROLLEYS	3 3/8	13	0	0	13								
	3 5/8	11	2	2	11								
	3 7/8	10	3	4	9								
	4	9	4	4	9	9	0	0	9				
	4 1/8	8	5	5	8	8	1	1	8				
	4 5/8	5	8	8	5	5	4	4	5				
SPECIAL TROLLEYS	5	3	10	10	3	3	6	6	3	8	0	0	8
	5 1/8	3	10	11	2	3	6	7	2	8	0	1	7
	5 1/4	2	11	12	1	2	7	8	1	7	1	2	6
	5 1/2	0	13	13	0	0	9	9	0	5	3	3	5
	5 5/8	12	1	1	12	8	1	1	8	4	4	4	4
	6	10	3	3	10	6	3	3	6	2	6	6	2
SPECIAL TROLLEYS	6 1/4	9	4	5	8	5	4	5	4	0	8	7	1
	6 3/8	8	5	6	7	4	5	6	3	0	8	8	0
	7	4	9	9	4	0	9	9	0	4	4	4	4
	7 1/8	3	10	10	3					4	4	5	3
	7 1/4	3	10	11	2					3	5	5	3
	7 3/8	2	11	12	1					2	6	6	2
7 1/2	1	12	12	1					1	7	7	1	
7 5/8	0	13	13	0					0	8	8	0	
* MINIMUM BEAM RADIUS		4'-0"				5'-6"							

* DIMENSION APPLIES TO MINIMUM I-BEAM AND WILL VARY WITH LARGER I-BEAMS

*Dimension applies to minimum I-beam and will vary with larger I-beams.

Enclosed Collectors and Wiring

Collectors can be installed on either side of a plain trolley and on plain side of a geared or motor driven trolley.

Installation Procedure —

1. Make sure that power supply to conductor system is shut off.
2. Refer to Figure 3 to determine the proper mounting position for the collector bar and bracket.
3. Attach the brackets by inserting the screws into tapped holes in the side frames. Tighten screws securely.
4. Place an insulator on collector bar.
5. Position the bar in the bracket and lock with set screws. Mount collectors on bar to match conductor system.
6. Again refer to Figure 3; position the collectors on the bar as shown.
7. Measure the length of power cable needed to reach the farthest collector. Allow for connecting the wire to the collector shunt screw and cut off the cable.
8. Strip back the insulation as required and cut off Green wire if no ground conductor is installed.

9. Attach wires to collector's shunt terminal, shunt terminal screw is internal (refer to Fig. 2 and Page 40).
10. Check installation to make sure that the collectors make proper contact throughout the entire length of trolley travel.
11. Energize conductor system. Check for proper direction of hook travel by following instructions on page 3.

Enclosed Collector





FIGURE 2

Hook Suspension



For hook suspension hoists, the supports for *each* hook must be capable of sustaining the hoist plus a capacity load, due to the fact that the load moves horizontally as it is raised and lowered.

HORIZONTAL TRAVEL OF LOWER HOOK BLOCK

PARTS OF ROPE	LIFT IN FEET	DIMENSION "A" IN INCHES	
		HIGH HOOK	LOW HOOK
2	20	4 1/2	8 3/8
4	18	1 1/4	4 3/4
6	22	*5	5 1/2

*Minimum dimension for "A" is 3" when hook is 10 ft. from hoist.

Dimension "A" is measured from the center of suspension bolt at control end. Hook is on center when hoist is viewed from end.

All Trolleys

For all trolley supported hoists, rail stops must be installed. These stops must not be positioned to exert impact force on the hoist but should contact the trolley side frames.

A chart on page 7 shows the number of spacer washers to be installed between trolley side frames and hoist suspension lugs for the nominal beam sizes indicated. It is suggested that the beam flange width be measured and trolley side frames be temporarily installed on hoist before installation to determine the exact distribution of washers. The distance between trackwheel flanges should be 1/8 to 3/16 inch greater than the beam flange width for straight runway beams, and 3/16 to 1/4 inch if runway system includes sharp curves. The number of washers between side frames and hoist lugs should be the same or differ

only by one washer, in order to keep the hoist hook centered under runway beam. The distribution of washers outside the trolley frames is unimportant except that the total number used must be sufficient to keep the slotted nuts and cotter pins in engagement.

When installing hoist and trolley on beam, tighten slotted nuts snugly so that the trolley frames are parallel and vertical. Do not over-tighten.

The suspension bolts are made of heat treated steel and should not be replaced with ordinary medium carbon steel bolts.

WARNING: Deviation from CM washer adjustment recommendations could cause the trolley to fall from the beam. The trolley should be inspected periodically to assure its continued safe operation.

Plain and Geared Trolleys

These trolleys are shipped separately and must be properly adjusted by the customer to fit runway beam.

On a geared trolley, the hand chain wheel should be installed on drum side of hoist. The weight of hoist motor will then counterbalance hand chain pull when the hoist is moved without a load. Before operating trolley, lubricate trackwheel gears with Texaco Novatex No. 2 or an equivalent heavy cup grease or graphite grease. If it is necessary to change the length of the hand chain, find the unwelded link and open it by spreading with a chisel or twist one end with a wrench while holding the other end in a vise or another wrench. Remove an *even number* of links (2, 4, 6, etc.) as necessary to shorten the chain or add an even number to lengthen it (in this latter case, another open link will be required, which can

be made from a welded link by cutting through the weld with a hacksaw). Make certain that the chain is not twisted — then re-install and close the open link.


With a capacity load on hoist, operate trolley over the entire length of runway or monorail system to be sure that the adjustment and operation is satisfactory.

On the 5-ton unit, the two suspension bolts supplied with trolley fit the end holes of side frames. Center hole is for sheave housing support pin, which is supplied with hoist. Slide the pin until slot at the one end is just outside side frame. Lock pin in position by placing the keeper plate in slot and securing it in position with screw.

The suspension bolts are made of heat treated steel and should not be replaced with ordinary medium carbon steel bolts.

Lug Suspension

For lug suspension hoists, it is suggested that the unit be installed on supports of the following design and spacing.



If supports are to be located at A, remove a group of washers equal to thickness T.

If supports are to be located at B, keep all washers on the outside of hoist lugs and put spacers inside to keep hoist from shifting sideways. Spacers may be made from standard one inch pipe.

Both suspension members must be on the inside of hoist lugs, as at B, or both on the outside as at A. For proper balance and stress distribution, keep both A dimensions equal for outside suspension and both dimensions B equal for inside suspension.

The suspension bolts furnished with hoist are

heat treated alloy steel and dimensions given in the above diagram are based on the use of these bolts. If other suspension bolts are used, these dimensions will no longer apply and the supports must be designed to avoid excessive bending stresses.

Dimensions W and T given for the supports are calculated for ordinary medium carbon steel with a safety factor of five. Each support is designed for the hoist plus a capacity load.

The one-half inch dimension for suspension members on the outside of hoist must be held in order to permit removal of the cover on motor side of hoist.

All Hoists (Cont'd)

SHORTENING THE CONTROL CORD

If it is necessary to shorten the cord, it is recommended that a "Control Cord Alteration Kit" (WS-782) be obtained from the manufacturer. This kit contains all of the necessary solderless wiring terminals, insulators, clamp, and instructions for shortening the cord.

However, if the proper terminals, etc. are available the cord can be shortened by using the prepared end of the cord as a guide. After the hoist operates properly, disconnect the power supply, open control station, disconnect all wires and ground cable. Remove cord from control station and slide the grommet and retainer up on the cord.

Cut off the cord for a length equal to the distance the station is to be raised, measuring from

the end of the longest wire. Using the cut off piece of cord as a guide, strip outer insulation jacket and shorten individual wires (except green wire) to the lengths previously used. Strip insulation from each wire for the distance required for the appropriate terminal.

On the green wire, cut and strip insulation for 2-5/16" from the end of the insulation jacket. Slide clamp sleeve onto ground cable and form a tight loop as shown in figure 1. Crimp sleeve to secure loop. Insert control cord into control station and attach ground cable and reconnect wires per wiring diagram. Reposition grommet and secure same with retainer ring.

Reassemble cover and gasket and operate hoist and/or trolley in both directions to check correctness of electrical connections.




FIGURE 1
SHORTENING CONTROL CORD

FOREWORD (Cont'd)

study is essential to safe rigging operations. For rigging information, we recommend consulting a standard textbook on the subject.

The postage paid guarantee card included in the envelope with this manual should be filled in and mailed to the factory at once for recording and validating.

CM GUARANTEE

If any part proves defective within one year of shipment, we will replace the part at no charge, F.O.B. our factory, provided the part claimed defective is returned to our factory transportation prepaid.

We assume no responsibility for unauthorized repairs.

Use of materials or replacement parts other than CM manufacture may lead to dangerous operation. Accordingly, CM cannot be responsible in such cases and the guarantee would be void.

CM METEOR MONITOR

The Monitor is designed to protect the Meteor Hoist from excessive, infrequent overloads. The Monitor is not intended to be used as a scaling device for purposes of determining what is an appropriate or safe load to be lifted on a regular basis.

SECTION A – INSTALLATION

All Hoists

Before installing hoist, see that current to be used is same as that shown on hoist name plate.

Inspect external wiring for broken leads or damaged insulation which may have been caused during shipment or handling.

The hoist should be connected to a branch circuit which complies with the requirements of the National Electrical Code.


The I-beam or other suspension system should be permanently grounded.

Four bosses or feet are provided to support the hoist on the floor. These protect the hoisting rope and control station cord from chafing or cutting—also can be used to hold a rope or chain sling in place for lifting the hoist.

After hoist is mounted on its suspension system, remove large plug in top of gear housing and pour in the two 1-quart cans of SAE 80 oil furnished with hoist. Check oil level by removing small plug in gear housing cover. Oil level should be in line with bottom of hole. See that the oil filler plug in top, the drain plug in bottom of housing and the level plug in cover are tight.

Before operating hoist, remove shipping wedge located between hoist drum and frame.

Since a three-phase electric hoist motor can rotate in either direction, depending on the manner in which it is connected to the power supply, the direction of hook movement must be checked during original installation and each time hoist is moved to a new location. Serious damage can result if hook is run to the upper or lower limit of travel with hook operating in a direction opposite to that indicated by the control station. Therefore, proceed as follows:

Make temporary connections to power supply. Operate  UP control in control station mo-

mentarily. If hook raises, connections are correct and can be made permanent. If hook lowers, it is necessary to change direction by interchanging the RED lead—marked L2 and the BLACK lead—marked L3 of hoist power cable at power supply. Under no circumstance should internal wiring of control station be changed to reverse hook direction. Wiring is inspected and tested before leaving the factory.

CAUTION: (60 FPM Units Only)

The hoist will not operate in the hoisting direction unless the relay is energized. The relay, however, does not affect lowering, and the hoist will always lower. Pushing the "DOWN" control energizes the relay and closes the relay-maintain circuit which keeps the relay energized after the "DOWN" button is released. After relay is energized check power connections using same procedure as previously outlined.

NOTE: It is only necessary to energize the hoist in the down direction at initial "start-up" or in the event of an overload. It is not necessary to depress the DOWN control each time the hoist is operated.

If hoisting rope has been displaced from drum grooves during shipment or handling, operate lowering control until the rope is unwound as far as necessary. Rewind carefully, allowing it to seat properly in drum grooves.

Operate hoist over the full length of its rated lift, first checking the upper limit switch for correct operation. The hoisting operation should automatically stop when hook block contacts and slightly raises the limit switch weight. If adjustment is necessary see Page 12. At low hook position there should be at least 2 wraps of rope remaining on drum.

SAFETY CODES

"Each Meteor hoist is built in accordance with the specifications contained herein and at the time of manufacture complies with our interpretation of applicable sections of the American National Standard Institute Code B30.16-1973 "Overhead Hoists", the National Electrical Code (ANSI C-1) and the Occupational Safety and Health Act—1970. Since OSHA states that the National Electrical Code applies to all electric hoists, installers are required to provide current overload protection and grounding in keeping with the code. Users should check installation for compliance with the application, operation and maintenance requirements of this law.

"The safety laws for elevators where the lifting of people are involved and for dumbwaiters may specify construction details that are not necessarily incorporated in CM industrial hoists. We recommend the use of equipment that meets state and national safety codes. Columbus McKinnon Corporation cannot be responsible for applications other than those for which CM equipment is recommended."

FOREWORD

This manual contains important information to help you properly install, operate and maintain your Meteor Hoist for maximum performance, economy and safety.

Please study its contents thoroughly before putting your hoist into operation. By practicing correct operating procedures and by carrying out the recommended preventative maintenance suggestions, you will be assured of long, dependable and safe service.


After you have completely familiarized your-

self with the contents of this manual, we recommend that you carefully file it for future reference.


The information herein is directed to the proper use, care and maintenance of the Meteor Hoist and does not comprise a handbook on the broad subject of rigging.

A word about rigging. Rigging can be defined as the process of lifting and moving heavy loads using hoists and other mechanical equipment. Skill acquired through specialized experience and

Current Collector Mounting for Meteor Trolleys




DIMENSION	COLLECTOR SYSTEM	
	SHOE	WHEEL
S	4	4
T	3 ¹ / ₄	3 ¹ / ₄
U	1 ¹ / ₄	3



CAUTION:

Trolley beam should always be electrically grounded. Be sure that there is good electrical contact between trolley beam and trackwheels. Avoid the use of paint or other coatings on the beam flange which might form an insulation.

Bracket & Bar Arrangement



COLLECTOR SYSTEM

AMER. STD. I-BMS	SHOE		WHEEL	
	1/2-2 T	3 & 5	1/2-2 T	3 & 5
6	A	-	A	-
7	B	-	A	-
8	C	B	A	A
10	C	C	B	B
12	C	C	B	C
15 & Over	C	C	C	C